

Extraflame

Stufe a Pellet



PELLET STOVES

User manual

DELIZIA

Read the instructions carefully before installation, use and maintenance.

The instruction book is an integral part of the product.





Congratulations! You are now the owner of an Extraflame stove!

The Extraflame pellet stove is an ideal heating solution. It utilises the most advanced technology and is manufactured to the highest standards with a contemporary design, allowing you to enjoy the ambience and warmth of a natural flame in complete safety.

This manual tells you how to use your stove correctly. Please read the entire manual carefully before using your stove.

IMPORTANT

Make sure that the dealer completes the following box with the details of the authorised specialist who will help you if you have any problems in using your new pellet stove.

AUTHORISED SPECIALIST

COMPANY _____
Full name _____
Address _____ No. _____
Postal Code _____ City _____ County. _____
TEL. _____ FAX _____

All Extraflame products are manufactured according to the following directives:

- ❖ **89/106 CEE (Construction Products)**
- ❖ **89/366 CEE (EMC Directive)**
- ❖ **2004/108 CE (EMC Directive)**
- ❖ **2006/95 CE (Low Voltage Directive)**

And the following standards:

- ❖ **EN 14785**
- ❖ **EN 60335-1**
- ❖ **EN 60335-2-102**
- ❖ **EN 61000-3-2**
- ❖ **EN 61000-3-3**
- ❖ **EN 50366**
- ❖ **EN 55014-1**
- ❖ **EN 55014-2**





Index

| | |
|--|-----------|
| WARNINGS AND SAFETY DEVICES | 7 |
| Chapter 2 | |
| WHAT ARE PELLETS? | 8 |
| PELLET STORAGE..... | 8 |
| PELLET LOAD..... | 8 |
| Chapter 3 | |
| SAFETY DEVICES | 9 |
| WARM AIR BLOWER BREAKDOWN..... | 9 |
| FUME EXHAUSTER BREAKDOWN..... | 9 |
| PELLET FEED MOTOR BREAKDOWN..... | 9 |
| IGNITION FAILURE..... | 9 |
| TEMPORARY POWER FAILURE..... | 9 |
| ELECTRICAL SAFETY..... | 9 |
| EXHAUST FUME SAFETY..... | 9 |
| PELLET OVERHEATING SAFETY..... | 9 |
| Chapter 4 | |
| ASSEMBLY AND INSTALLATION INSTRUCTIONS | 10 |
| GLOSSARY..... | 10 |
| INSTALLATION..... | 11 |
| ADMISSIBLE INSTALLATIONS..... | 11 |
| PROHIBITED INSTALLATIONS..... | 11 |
| CONNECTION TO THE EXHAUST VENTING SYSTEM..... | 12 |
| EXHAUST CHANNEL OR PIPE..... | 12 |
| CHIMNEY OR SINGLE FLUE..... | 13 |
| CONNECTION TO THE FLUE AND COMBUSTION PRODUCT EXHAUST VENTING..... | 15 |
| CHIMNEY CAP..... | 15 |
| CONNECTION TO EXTERNAL AIR INTAKES..... | 16 |
| INSULATION, TRIMS, FACINGS, AND SAFETY PRECAUTIONS..... | 16 |
| NATIONAL, REGIONAL, PROVINCIAL AND MUNICIPAL LAWS..... | 16 |
| Chapter 5 | |
| PRODUCT FUNCTIONALITY | 17 |
| CONTROL BOARD..... | 17 |
| LANGUAGE SELECTION..... | 17 |
| CURRENT DATE AND TIME ADJUSTMENT..... | 18 |
| BASIC INSTRUCTIONS..... | 18 |
| IGNITION..... | 19 |
| STOVE FUNCTIONING..... | 19 |
| NORMAL FUNCTIONING..... | 19 |
| SWITCH-OFF..... | 20 |
| Chapter 6 | |
| REMOTE CONTROL | 21 |
| Chapter 7 | |
| ROOM THERMOSTAT | 22 |
| DIGITAL THERMOSTAT (AS PER STANDARD)..... | 22 |



| | |
|--|-----------|
| MECHANICAL THERMOSTAT (OPTIONAL) | 22 |
| MECHANICAL THERMOSTAT INSTALLATION (OPTIONAL) | 22 |
| MECHANICAL THERMOSTAT FUNCTIONING | 22 |
| MECHANICAL THERMOSTAT FUNCTIONING IN STDBY MODE (TO ALSO BE USED FOR TELEPHONIC ACTUATOR)..... | 23 |
| Chapter 8 | |
| USER PARAMETERS | 24 |
| OVEN FUNCTIONING MODES..... | 24 |
| PELLET OVEN MODE..... | |
| | 25 |
| NORMAL FUNCTIONING (NO TIMER) | 25 |
| TIMED FUNCTIONING (WITH TIMER) | 25 |
| ELECTRIC OVEN MODES | |
| | 25 |
| NORMAL FUNCTIONING (NO TIMER) | 26 |
| TIMED FUNCTIONING (WITH TIMER) | 26 |
| WEEKLY PROGRAMMER | 26 |
| DAY-NIGHT TEMPERATURE FUNCTION | 29 |
| PELLET FEED ADJUSTMENT | 30 |
| Chapter 9 | |
| CLEANING | 32 |
| CONNECTION TO THE FLUE | 33 |
| Chapter 10 | |
| POT DIVIDER..... | 34 |
| Chapter 11 | |
| PRODUCT DISPLAY TABLES | 35 |
| Chapter 12 | |
| WARRANT | 39 |



WARNINGS AND SAFETY DEVICES

The stoves produced by our establishment are built with attention to the individual components in a way to protect both the user and the installer from any accidents. It is therefore recommended that after any intervention on the product, authorised staff pay particular attention to the electric connections, especially the stripped parts of the wires. These must not escape from the terminal board in any situation, thus preventing possible contact with the live parts of the wire.

Installation must be carried out by authorised staff, who must provide the buyer with a declaration of conformity for the system and will assume full responsibility for final installation and as a consequence the correct functioning of the installed product. It is necessary to bear in mind all laws and national, regional, provincial and town council Standards present in the country the appliance has been installed.

Extraflame S.p.A. cannot be held responsible for the failure to comply with such precautions.

The instruction manual is an integral part of the product: make sure that it always accompanies the appliance, even if transferred to other owners or user or is transferred to another place. If it is damaged or lost, request another copy from the area technician.

This stove must be destined for the use for which it has been expressly realised. The manufacturer is exempt from any liability, contractual and extracontractual, for injury/damage caused to persons/animals and objects, due to installation, adjustment and maintenance errors and improper use.

After the packaging has been removed, check the integrity and completeness of the contents. If this does not comply, contact the dealer where the appliance was purchased.

All electric components that make up the stove must be replaced with original spare parts exclusively by an authorised after-sales centre, thus guaranteeing correct functioning.

The stove must be serviced at least once a year, programming it in advance with the technical after-sales service.

Nota bene: In case of thermo product or boiler, the product or system venting is not covered by the warranty.

For safety reasons, remember that:

- ❖ The stove must not be used by children or unassisted disabled persons.
- ❖ Do not touch the stove when you are barefoot or when parts of the body are wet or humid.
- ❖ The safety and adjustment devices must not be modified without the authorisation or indications of the

manufacturer.

- ❖ Do not pull, disconnect, twist electric cables leaving the stove, even if disconnected from the electric power supply mains.
- ❖ Do not close or reduce the dimensions of the airing vents in the place of installation. The airing vents are indispensable for correct combustion.
- ❖ Do not leave the packaging elements within reach of children or unassisted disabled persons.
- ❖ The hearth door must always be closed during normal functioning of the product.
- ❖ Avoid direct contact with parts of the appliance that tend to heat up during functioning.
- ❖ Check for the presence of any obstructions before switching the appliance on following a prolonged standstill period.
- ❖ The stove has been designed to function in any climatic condition (also critical). In particularly adverse conditions (strong wind, freezing) safety systems may intervene that switch the stove off. If this occurs, contact the technical after-sales service and always disable the safety system.
- ❖ If the flue should catch fire, be equipped with suitable systems for suffocating the flames or request help from the fire service.

MAJOLICAS

The company have chosen majolica tiles, which are the result of high-quality artisan work and therefore the majolica may present crackles, speckles, and shadings. These characteristics certify their precious origin.

Enamel and majolica, due to their different coefficient of dilatation, produce microcrackles, which show their authentic feature.

For the cleaning of the majolica we suggest you use a soft and dry cloth; if you use a detergent or liquid, the latter might soak in and make the crackles more visible.

WHAT ARE PELLETS?

Pellets are made by applying very high pressure to sawdust; i.e. the residue of raw timber (without paint) produced by sawmills, carpentry works and other activities involved in processing wood.

This type of fuel is completely environmentally friendly, as no binders of any kind are used to keep it compact. In fact, the compactness of the pellets over time is guaranteed by lignin, a natural substance found in the wood itself.

As well as being an environmentally friendly fuel, since wood residues are exploited to the maximum, pellets also have technical advantages.

The density of the pellet is 650kg/m³ and the water content is 8% of its weight. For this reason, pellets do not need to be seasoned to obtain a sufficient heating yield.

Pellets used must be compliant with norms:

- ❖ Ö-Norm M 7135
- ❖ DIN plus 51731
- ❖ UNI CEN/TS 14961

Extraflame recommends using 6 mm pellets.

WARNINGS!!!



THE USE OF OUT OF DATE PELLETS OR ANY OTHER MATERIAL, DAMAGES YOUR STOVES' FUNCTIONS AND CAN DETERMINE THE END OF THE WARRANTY AND THE PRODUCER'S ANNEXED RESPONSIBILITY.

PELLET STORAGE

To guarantee problem-free combustion, the pellets must be stored in a dry place.

PELLET LOAD

To load the pellets, open the tank cover positioned on the upper part of the stove and empty the bag of pellets, paying attention not to let them escape.

For the Inserto Comfort Maxi model consult the "Inserto Comfort Maxi Installation" chapter.

For Falò models consult the "Falò 1XLP, Falò 1CP and Falò 2CP" chapter".



figure 2.1



SAFETY DEVICES

WARM AIR BLOWER BREAKDOWN

If the blower stops for any reason, the stove automatically shuts down to prevent overheating.

FUME EXHAUSTER BREAKDOWN

If the exhauster stops, the electronic unit immediately prevents pellet feeding.

PELLET FEED MOTOR BREAKDOWN

If the motor stops, the stove continues to operate until the minimum cooling level is reached.

IGNITION FAILURE

If a flame is not developed during the ignition phase, the appliance automatically attempts ignition again, this time without pellet feeding.

If no flame develops also in this case, the appliance will signal **"IGNITION FAILURE"** on the display. When trying to re-ignite the machine, it will indicate **"WAIT FOR COOL."** on the display. **This function reminds that before performing ignition, it must be ensured that the pot is completely free and clean.**

TEMPORARY POWER FAILURE

The appliance will re-light automatically after a brief power failure. When the power goes off, the stove may emit a minute quantity of smoke inside the house for a period of 3 to 5 minutes.

THIS DOES NOT POSE ANY SAFETY RISK.

ELECTRICAL SAFETY

The stove is protected against violent power swings by a master fuse on the rear of the stove (2A 250V delayed).

EXHAUST FUME SAFETY

If the exhaust system fails, an electronic pressure switch stops the stove and an alarm is signalled.

PELLET OVERHEATING SAFETY

In case of overheating inside the pellet hopper, this safety device blocks stove operation; resetting is manual and must be performed by an authorized technician.

ASSEMBLY AND INSTALLATION INSTRUCTIONS

The installation must comply with:

- ❖ *UNI 10683 (2005) heat generators fed with wood and other solid fuels: installation.*

The chimneys must comply with:

- ❖ *UNI 9731 (1990) chimneys: classification according to thermal resistance.*
- ❖ *EN 13384-1 (2006) calculation method of the thermal and fluid-dynamic features of the chimney.*
- ❖ *UNI 7129 point 4.3.3 provisions, local rules and prescriptions of the fire brigade.*
- ❖ *UNI 1443 (2005) chimneys: general requirements.*
- ❖ *UNI 1457 (2004) chimneys: internal ducts in terracotta and ceramics.*

GLOSSARY

CLOSED HEARTH DEVICE

Heat generator that can only be opened to load fuel during use.

BIOMASS

Material of organic origin, excluding the material incorporated in geological formations and fossilised.

BIOFUEL

Fuel produced directly or indirectly from biomass.

FLUE or CHIMNEY

Vertical duct for collecting and expelling combustion products from a single appliance at a suitable height from the floor.

EXHAUST CHANNEL OR PIPE

Duct or connecting element between the heat generating device and the chimney for extracting the combustion products.

INSULATION

The series of measures taken and materials used to prevent heat transmission through a wall dividing rooms at different temperatures.

CHIMNEY CAP

Device located at the top of the chimney that facilitates dispersion of the combustion products in the atmosphere.

CONDENSATE

Liquid products that form when the temperature of the combustion gas is lower than or equal to the dew point of the water.

HEAT GENERATOR

Device that permits the production of thermal energy (heat) by the rapid transformation of the chemical energy of the fuel by means of combustion.

AIR LOCK

Mechanism for modifying the dynamic resistance of the combustion gasses.



EXHAUST VENTING SYSTEM

A system for fume exhaust venting that is independent from the appliance, composed of a pipe or channel, chimney or single flue, and chimney cap.

FORCED DRAUGHT

Air circulation by means of a fan driven by an electric motor.

NATURAL DRAUGHT

Draught resulting in a chimney/flue due to the difference in the volume mass existing between the (hot) fumes and the surrounding atmospheric air, without any mechanical suction aid installed inside or on top of it.

RADIANCE AREA

Area immediately adjacent to the hearth in which the heat produced by combustion is diffused; this area must not contain any objects made of combustible material.

REFLUX AREA

Area in which the combustion products come out from the appliance towards the room in which it is installed.

INSTALLATION

Before carrying out installation, it is necessary to check the positioning of the chimneys, flues or exhaust terminal ducts of the appliance, keeping in mind the following:

- ❖ Installation prohibitions
- ❖ Legal clearances
- ❖ Limitations set forth by local administrative regulations or specific regulations of the authorities.
- ❖ Common limitations deriving from building regulations, and easement or contract regulations.

ADMISSIBLE INSTALLATIONS

In the room in which the heat generator is to be installed, any existing or installed appliances must be airtight to the room and must not cause depression in the room with respect to the external environment.

Appliances used for cooking foods and the related hoods without extractor can only be installed in rooms used as kitchens.

PROHIBITED INSTALLATIONS

The room in which the heat generator is to be installed must not contain any of the following devices, either pre-existing or installed:

- ❖ Hoods with or without extractor;
- ❖ Ventilation ducts of the collective type.

Should these devices be located in adjacent rooms communicating with the installation room, it is forbidden to use the heat generator simultaneously where there is the risk that one of the two rooms may be subject to depression with respect to the other.

CONNECTION TO THE EXHAUST VENTING SYSTEM

EXHAUST CHANNEL OR PIPE

For the assembly of the exhaust channels it is imperative to use non-flammable materials that are resistant to combustion products and any condensates.

It is forbidden to use flexible metal pipes and asbestos cement for connecting the stove to the flue, also for pre-existing exhaust channels.

There must be continuity between the exhaust channel and the flue so that the flue does not lean on the stove.

The exhaust channels must not pass through rooms in which the installation of combustion devices is forbidden.

The assembly of the exhaust channels must be carried out in such a way as to ensure that they are airtight for the operating conditions of the appliance, as well as to limit the formation of condensates and prevent them from being conveyed towards the appliance.

The assembly of horizontal sections must be avoided where possible.

Where roof or wall exhaust outlets have to be reached that are not coaxial in relation to the exhaust outlet from the appliance, the direction changes must be made using open elbows no greater than 45° (see figures below).




figure 4.1




figure 4.2

For heat generating devices equipped with an electric exhaust fan, i.e. all products made by Extraflame, it is necessary to observe the following instructions:

- ❖ Horizontal sections must have a minimum slope of 3% upwards.
- ❖ The length of the horizontal section must be as short as possible, and in any case no greater than 3 meters.
- ❖ No more than four direction changes may be used, including the one resulting from the use of the "T"-element. (When four bends are used, use double wall piping with a 120 mm diameter.)

In any case, exhaust channels must be sealed in relation to combustion products and condensates, as well as insulated, if they pass outside the installation room.

It is forbidden to use elements in counter-slope.

The exhaust channel must allow soot recovery and cleaning using a swab.

The exhaust channel must have a constant cross-section. Any changes in cross-section are allowed only at

the flue connection.

It is forbidden to run other air feed channels or piping for utilities inside the exhaust channels, even if they are oversized. It is also forbidden to fit manual draught adjustment devices on the forced draught appliance.

CHIMNEY OR SINGLE FLUE

The chimney or flue must meet the following requirements:

- ❖ be airtight to combustion products, waterproof and properly insulated according to the usage conditions;
- ❖ be made of materials suitable to resist normal mechanical stress, as well as heat and the action of combustion products and any condensates;
- ❖ have a predominantly vertical layout with deviations from the axis no greater than 45°;
- ❖ be situated at a proper distance from combustible or flammable materials by means of an air gap or suitable insulation material;




figure 4.3




figure 4.4

| REFERENCES | Flammable objects | Non-flammable objects |
|------------|-------------------|-----------------------|
| A | 200 | 100 |
| B | 1500 | 750 |
| C | 200 | 100 |

- ❖ preferably have a round internal section: square or rectangular sections must have rounded edges with radius no less than 20 mm;
- ❖ have a constant, free and independent internal section;
- ❖ have rectangular sections with a maximum ratio between sides of 1.5.

The exhaust duct should be equipped with a chamber for the collection of solid materials and any condensates located below the mouth of the exhaust channel, so that it is easy to open and inspect from the airtight hatch.




figure 4.5




figure 4.6




figure 4.7




figure 4.8

CONNECTION TO THE FLUE AND COMBUSTION PRODUCT EXHAUST VENTING

The flue must receive exhaust from a single heat generator.

Direct discharge towards enclosed areas, even when roofless, is forbidden.

Direct discharge of combustion products must take place on the roof and the exhaust duct must have the features set forth in the section "Chimney or single flue".

CHIMNEY CAP

The chimney cap must meet the following requirements:

- ❖ have an internal section equivalent to that of the chimney;
- ❖ have a useful outlet section no less than twice the internal section of the chimney;
- ❖ be constructed in such a way as to prevent the penetration of rain, snow and foreign bodies into the chimney, as well as to assure the discharge of the combustion products also in the presence of winds coming from any direction and at any angle.
- ❖ be positioned in such a way as to assure proper dispersion and dilution of the combustion products and, in any case, outside the reflux area in which the formation of counter-pressure is most likely to occur. This area has different sizes and shapes depending on the slope of the roof; therefore, it is necessary to use the minimum heights indicated in the figures below.
- ❖ The chimney cap must not have any mechanical suction devices.

FLAT ROOF




figure 4.9

SLOPED ROOF




figure 4.10

| CHIMNEYS, DISTANCES AND POSITIONING | | |
|--|---|---|
| Roof pitch | Distance between the crown and the chimney | Minimum height of the chimney (measured from the outlet) |
| β | A (m) | H (m) |
| 15° | < 1,85 | 0,50 m beyond the crown |
| | > 1,85 | 1,00 m from the roof |
| 30° | < 1,50 | 0,50 m beyond the crown |
| | > 1,50 | 1,30 m from the roof |
| 45° | < 1,30 | 0,50 m beyond the crown |
| | > 1,30 | 2,00 m from the roof |
| 60° | < 1,20 | 0,50 m beyond the crown |
| | > 1,20 | 2,60 m from the roof |

CONNECTION TO EXTERNAL AIR INTAKES

To ensure correct operation, the appliance must have sufficient air available by means of external air intakes, which must meet the following requirements:

1. They must have a total free section of at least 80 cm².
2. They must be protected by a grate, metal mesh, or other suitable protection provided that it does not reduce the minimum section as per point a) and that it is positioned in such a way as to prevent the intakes from being obstructed.

If the combustion air is collected directly from the outside by means of a pipe, it is necessary to fit a downward bend or a wind hood on the outside. In addition, no grating or similar device should be positioned. (Extraflame S.p.A. suggests creating an air intake directly communicating with the installation room, even if air is collected from outside by means of a pipe).

Air inflow can also be obtained from a room adjacent to the installation room, provided that the flow can occur freely through permanent openings communicating with the outside.

The adjacent room must not be subject to depression with respect to the outside as a result of the opposing draught caused by the presence of another utility device or suction device in this room.

In the adjacent room, the permanent openings must meet the requirements described above.

The adjacent room cannot be used as a garage, storage area for combustible material, or for activities involving fire hazards.

INSULATION, TRIMS, FACINGS, AND SAFETY PRECAUTIONS

The facings, no matter what type of material they are made of, must constitute a self-bearing structure with reference to the heating assembly and not in contact with it.

The beam and the trims in wood or combustible materials must be positioned outside of the radiant area of the hearth or be properly insulated.

If the space above the heat generator has coverings made of combustible or heat-sensitive material, a protective membrane made of non-combustible insulating material must be placed between it and the generator.

All elements made of combustible or flammable material, such as wooden furnishings, curtains, etc., that are directly exposed to the radiance of the hearth must be placed at a safe distance.

The installation of the appliance must guarantee easy access for cleaning the appliance itself, of the waste gas pipes and the flue.

NATIONAL, REGIONAL, PROVINCIAL AND MUNICIPAL LAWS

All the national, regional, provincial and municipal laws of the country where the appliance has been installed must be taken into consideration.

PRODUCT FUNCTIONALITY

CONTROL BOARD




figure 5.1

1 ⇒ ON/OFF BUTTON

By pressing button 1 it is possible to switch the stove on and off automatically.

2-3 ⇒ AIR TEMPERATURE SETTING

Buttons 2 and 3 are used to adjust the room temperature inside the house.

4-5 ⇒ FUNCTIONING POWER

Use buttons 4 and 5 to adjust the heating power that goes from a minimum of 4.5 kW/h to a maximum of 23 kW/h.

Displays D1 and D2 show the various messages.

LANGUAGE SELECTION



Controls procedure

1. Remove and restore the stove power supply using the master switch or using the power supply cable.
2. The stove will first display the microprocessor version (**OVEN_1** or successive), "**LANGUAGE**", "**CLOCK**", "**LEVEL**" and then "**OFF**".
3. When "**LANGUAGE**" appears, press button 5 to access the adjustment mode.

Display D1 will show the language currently selected while display D2 will show "LANG": use keys 2 and 3 to select the language from those available: **ITALIAN - ENGLISH - GERMAN - FRENCH - SPANISH - FINNISH - PORTUGUESE - NORWEGIAN - DUTCH**

4. Once the desired language has been selected, press button 1 to escape and confirm.

CURRENT DATE AND TIME ADJUSTMENT



Controls procedure

1. Remove and restore the stove power supply using the master switch or using the power supply cable.
2. The stove will first display the microprocessor version (**OVEN_3** or successive), "**LANGUAGE**", "**CLOCK**", "**LEVEL**" and then "**OFF**".
3. When "**CLOCK**" appears, press button 5 to access the adjustment mode.
4. Display D1 will show a day of the week (from **DAY 1** to **DAY 7**):
5. use keys 2 and 3 to set the current day and confirm using button 5.

| D1 display | Meaning |
|--------------|-----------|
| DAY 1 | Monday |
| DAY 2 | Tuesday |
| DAY 3 | Wednesday |
| DAY 4 | Thursday |
| DAY 5 | Friday |
| DAY 6 | Saturday |
| DAY 7 | Sunday |

6. Display D1 will show the current time, the hours flashing while the minutes are fixed: use keys 2 and 3 to adjust the time and then confirm using key 5.
 7. At this point the hours will become fixed and the minutes will start to flash: use keys 2 and 3 to adjust the minutes.
- To go back to selection of the hours, press button 4 again or escape and confirm using button 1.

BASIC INSTRUCTIONS

The stove you have purchased uses pellet fuel. This type of material is obtained from natural waste from the machining of wood. By means of a special process that does not require the use of any binding agent and additive, the waste is compressed in industrial machinery under high pressure and it becomes solid wooden pellets.

IT IS PROHIBITED to burn non-pelletised raw materials inside our stoves. The failure to comply with these prescriptions voids all guarantees and could jeopardise the safety of the appliance.

The following recommendations must be followed the first two or three times the stove is ignited:

- ❖ no children must be present because the vapours emitted can be noxious to health. Adults should also avoid long stays.
- ❖ Do not touch the surfaces as they could still be unstable.
- ❖ Air the room well several times.
- ❖ The hardening of the surfaces is terminated after several heating processes.
- ❖ This appliance **must not** be used to burn waste.

IGNITION

1. Before switching the stove on, the following points must be verified:
 - a. the feed-box must be full of pellets
 - b. the combustion chamber must be clean
 - c. the pot must be completely free and clean
 - d. check the hermetic closure of the fire door and the ash drawer
 - e. make sure the power supply cable is connected correctly
 - f. the bipolar switch in the rear right part must be positioned on 1
2. Press button 1 for 3 seconds: display D1 will show "**START**", while on display D2, starting from number 8, the numbers will decrease every second. In this phase the appliance performs self-analysis to check the functionality of each individual electric component. When this cycle has been completed, display D1 will show "**IGNITION**", while display will show "15" (these are the minutes when the stove attempts the ignition phase and decreases by 1 every minute that passes). NOTE: The first time the product is used, even if the feed-box is full, there is the possibility that the pellets are not distributed into the combustion chamber for the first 15 minutes. This is because the pellet feed worm screw is empty. If no flame has developed in the stove after 15 minutes D1 will show "**IGNITION FAILURE**". If points 1 and 2 have been performed correctly, when the flame is developed the stove will pass to "**START**" mode.
3. On termination of the start phase the stove will pass to normal functioning: display D1 will show the room temperature while display D2 will show the work power.

ATTENTION!!!



1. DO NOT USE ANY INFLAMMABLE LIQUIDS FOR IGNITION
2. DO NOT ALLOW THE BAG OF PELLETS TO COME INTO CONTACT WITH THE BOILING HOT STOVE DURING THE FILLING PHASE

N.B. In the case of continuous ignition failure, contact an authorised technician.

STOVE FUNCTIONING

NORMAL FUNCTIONING

When ignition has taken place, the user can adjust the heating power using buttons 4 and 5. By pressing button 4 the heat power is decreased and therefore also the consumption of pellets per hour, vice versa by pressing 5, the heating power is increased and as a consequence also pellet consumption. As well as the adjustment of flow rate it is also possible to adjust the room temperature directly from the control board. Regarding the ventilation of hot air the stove adjusts itself automatically.

Check the content of the feed-box in order to prevent the fire going out due to the lack of fuel.



ATTENTION!!!



1. The lid of the pellet container must always be closed. It must only be opened during the fuel loading phase.
2. The bags of pellets must be kept at least 1.5 metres from the stove.
3. It is recommended that the feed-box is always half full.
4. Make sure the appliance is off before filling the pellet feed-box.

SWITCH-OFF

Press button 1 for three seconds.

When the operation has been performed, the appliance automatically enters the switch-off phase, blocking the supply of pellets; display D1 will alternately show “**OFF**” and room temperature while display D2 will show the current time.

Both of the motors used for fumes extraction and ventilation of the hot air will stay on until the temperature of the stove has dropped sufficiently.

REMOTE CONTROL

The heat setting, the room temperature, and automatic start/stop of the stove can be remote controlled.

S = Luminous warning light that indicates which keys have been pressed.

Correspondence of display keys with remote control keys

- 1 = p3+p5
- 2 = p2
- 3 = p3
- 4 = p4
- 5 = p5




figure 6.1

To light the stove, press buttons 3 and 5 at the same time and hold for three seconds (Fig. 21); the stove automatically enters the lighting stage. This is followed by the start-up phase, which allows the stove to develop and settle the flame. When the lighting stage is complete, the stove goes into normal operation. The heat setting can be adjusted using the buttons 5 and 4, and the room temperature setting can be adjusted using buttons 2 and 3.

To switch off the stove, press buttons 3 and 5 at the same time and hold for three seconds. Display D1 will show the message **"OFF"**.

The remote control operates with an MN21 12V battery (the kind used for gate openers).

To replace the batteries, open the cover in the rear part as illustrated below.



figure 6.2



figure 6.3

Open by pressing the part circled in the figure

ROOM THERMOSTAT

DIGITAL THERMOSTAT (AS PER STANDARD)

The appliance can control the room temperature using a digital thermostat, which can lower the heating power to minimum when a pre-set temperature is reached.

1. When the stove is started and has entered normal functioning mode, display D1 will show a number (e.g. 21°C); this value indicates the room temperature.
2. Use buttons 2 or 3 to enter the thermostat setting and the display will show a flashing word that alternates at every impulse with **"SET"** and the temperature to be set; by pressing 2 the value decreases and by pressing 3 it increases.
3. When the desired temperature has been adjusted let **"SET"** disappear from the display.
4. Adjust the desired heating power using buttons 4 and 5.

When the appliance reaches the temperature set it automatically goes to a minimum functioning mode and the relative luminous indicator switches-off in display D1.

If digital thermostat functioning thermostat is to be excluded, use button 3, to take the temperature to maximum until **"MANUAL"** appears in display D1.

The same functions can be obtained using the remote control.

MECHANICAL THERMOSTAT (OPTIONAL)

N.B: Installation must be performed by an authorised technician.

It is possible to thermostat a room adjacent to the room where the stove is positioned: just connect a mechanical thermostat (boiler type) following the procedure described in the next point (it is recommended to position the optional mechanical thermostat at a height of 1.50m from the ground).

MECHANICAL THERMOSTAT INSTALLATION (OPTIONAL)

N.B: Installation must be performed by an authorised technician.

1. Switch the appliance off using the master
2. switch positioned on the rear of the stove
3. Remove the plug from the socket
4. Refer to the wiring diagram to connect the two thermostat cables onto the relative clamps positioned don the rear of the machine, one is red and the other black.

MECHANICAL THERMOSTAT FUNCTIONING

1. Set the desired heating power using buttons 4 and 5.
2. Using button 2 take the room temperature to minimum and **"MINIMUM"** will appear on the display.
 - ❖ Adjust the desired room temperature using the thermostat (e.g. 21 C°) and **"T ON"** will appear on the display.
3. When the stove reaches the desired temperature, it will go to minimum working conditions (**"MINIMUM"** will appear on D1). If the temperature lowers, the appliance will go back to **"T ON"** taking back the previously left functioning setting.



MECHANICAL THERMOSTAT FUNCTIONING IN STDBY MODE (TO ALSO BE USED FOR TELEPHONIC ACTUATOR)

The Stdby function is also used to further reduce fuel consumption by switching the stove off when the desired temperature is reached. On the contrary, if the temperature drops, the stove automatically switches back on, going to normal working conditions.

1. Set the desired heating power using buttons 4 and 5.
2. Using button 2, take the room temperature to minimum until "**MINIMUM**" with "**SET**" flashing appears in display D1.
3. At that point while "**SET**" with "**MINIMUM**" continue to flash, press key 1 for three seconds and the display will show "**STBY**". At this point the energy saving function is activated.

At this point the external thermostat will control stove functioning in the following way:

- ❖ Closed contact thermostat ⇒ the stove switches on and works at the set power, showing "**T ON**" on display D1.
- ❖ Open contact thermostat ⇒ the stove switches off or stays off showing "**STBY**" on display D1.

This function can be suspended temporarily by pressing key 1:

- ❖ If from "**STBY**" ⇒ the stove will remain off alternately showing "**STBY**", "**OFF**" on display D1 and the current time on display D2.
- ❖ If from "**T ON**" ⇒ the stove switches off alternately showing "**T ON**", "**OFF**" on display D1 and current time on the display D2.

To go back to using the function, press button 1 again.

To definitively exclude the function just raise the temperature of the stove thermostat using button 3.

USER PARAMETERS

| USER PARAMETERS | | |
|--------------------------------|-------------|---|
| OVEN FUNCTIONING MODES | | |
| Display D1 | Display D2 | Function |
| OVEN / 170°C | OFF | Act./Deact. Oven / Oven temperature adjustment |
| TIMER / 000' | | Act./Deact. Timer / Timer adjustment |
| WEEKLY PROGRAMMER | | |
| Display D1 | Display D2 | Funzione |
| CHRONO | OFF | Act./Deact. Weekly programmer |
| OFF | UT 1 | Time 1st switch-on |
| OFF | UT 2 | Time 1st switch-off |
| OFF 1 | UT 3 | Consents for 1st switch on/off for various days |
| 00 | UT 4 | Installer parameter |
| OFF | UT 5 | Time 2nd switch-on |
| OFF | UT 6 | Time 2nd switch-off |
| OFF 1 | UT 7 | Consents for 2nd switch on/off for various days |
| OFF | UT 8 | Time 3rd switch-on |
| OFF | UT 9 | Time 3rd switch-off |
| OFF 1 | UT A | Consents for 3rd switch on/off for various days |
| DAY-NIGHT TEMPERATURE FUNCTION | | |
| Display D1 | Display D2 | Function |
| 06:00 | B | Start of day time/end of night time |
| 22:00 | C | Start of night time/end of day time |
| 25 | D | Day time max. temperature |
| 20 | E | Night time max. temperature |
| PELLET FEED ADJUSTMENT | | |
| Display D1 | Display D2 | Function |
| 00 | F | % pellet feed adjustment |

OVEN FUNCTIONING MODES

The Delizia model associates normal functioning of a pellet stove with the functioning of an food oven. It allows to keep the cooking of your foods constant thanks to a digital thermostat.

The oven has a maximum capacity of about 30 litres. It is enamelled and has an automatic light in order to see the foodstuffs during cooking.

Two completely distinct functioning modes have been envisioned on the stove regarding the oven: **PELLET OVEN** mode and **ELECTRIC OVEN** mode.

The pellet oven mode can only be activated when the stove is on as the oven is heated by the heat developed by combustion of the pellets. In this mode the oven has a temperature range from 170 to 250°C.

The electric oven mode can only be activated with the stove off and completely cold and envisions heating of the oven by two electric resistances (the two resistances are respectively 1500 and 800 W). In this mode the oven has a temperature range from 70 to 250°C.



PELLET OVEN MODE

Before proceeding make sure that the stove is on. In oven mode, the stove adapts its work to give priority to heating the oven; this implies that it is not possible to modify the work power.

All stove automatic functions will also be temporarily suspended (weekly programmer, day-night temperature function and external thermostats functioning). The automatic functions will become active again on deactivation of the oven.

To activate this mode it is necessary to enter the user parameters, i.e. press key 3, hold it down and then press key 5. Now release both keys at the same time.

Display D2 shows "**ON/OFF**" which will allow to enable/disable oven functioning, by pressing key 4.

Display D1 will show 2 flashing messages: "**OVEN**" and the temperature for the oven "170 - 250" (minimum and maximum). Adjust the desired temperature using keys 2 and 3.

Once the oven is activated and the temperature adjusted, press button 5 to confirm and continue.

"**TIMER**" will appear flashing on D1 followed by "**OFF**" or a time expressed in minutes "**000 - 255**"; at this point two functions can be selected: normal or timed functioning.

NORMAL FUNCTIONING (NO TIMER)

Use buttons 2 and 3 to adjust the timer to "**OFF**". The stove will work to take the oven to the pre-established temperature without any time limit. To confirm and escape press button 5.

In this mode display D1 will show running "**PELLET OVEN**", while display D2 will show the current temperature of the oven (the temperature will be shown starting from 60°C; below this the display will show - - -).

TIMED FUNCTIONING (WITH TIMER)

Use buttons 2 and 3 to adjust a desired working time. The stove will work to take the oven to the pre-established temperature. At the end of the set working time stove display D1 will show "**END OF COOKING**": at this point the stove will go to 1st power. To confirm and escape press button 5.

In this mode, two messages will appear alternately on the 2 displays:

- ❖ In this mode display D1 will show running "**PELLET OVEN**" accompanied by the current temperature of the oven on display D2 (the temperature will be shown starting from 60°C; below this the display will show - - -).

- ❖ display D1 will show "**TIMER**" accompanied by the remaining time on the timer on display D2. It will be possible to modify the remaining time using keys 2 and 3.

ELECTRIC OVEN MODES

Before proceeding make sure that the stove is off completely and cold.

To activate this mode it is necessary to enter the user parameters, i.e. press key 3. hold it down and then press key 5. Now release both keys at the same time.

Display D2 shows "**ON/OFF**" which will allow to enable/disable oven functioning, by pressing key 4.

Display D1 will show 2 flashing messages: "**OVEN**" and the temperature for the oven "**70 - 250**" (minimum and maximum). Adjust the desired temperature using keys 2 and 3.



Once the oven is activated and the temperature adjusted, press button 5 to confirm and continue. **"TIMER"** will appear flashing on D1 followed by **"OFF"** or a time expressed in minutes **"000 - 255"**; at this point two functions can be selected: normal or timed functioning.

NORMAL FUNCTIONING (NO TIMER)

Use buttons 2 and 3 to adjust the timer to **"OFF"**. The stove will work to take the oven to the pre-established temperature without any time limit. To confirm and escape press button 5.

In this mode display D1 will show running **"ELECTRIC OVEN"**, while display D2 will show the current temperature of the oven (the temperature will be shown starting from 60°C; below this the display will show - - - -).

TIMED FUNCTIONING (WITH TIMER)

Use buttons 2 and 3 to adjust a desired working time. The stove will work to take the oven to the pre-established temperature. At the end of the set working time stove display D1 will show **"END OF COOKING"**: at this point the temperature of the oven will lower to the maintenance temperature of 70°C. Use button 5 to confirm and escape.

In this mode, two messages will appear alternately on the 2 displays:

In this mode display D1 will show running **"ELECTRIC OVEN"** accompanied by the current temperature of the oven on display D2 (the temperature will be shown starting from 60°C; below this the display will show - - - -).

- display D1 will show **"TIMER"** accompanied by the remaining time on the timer on display D2. It will be possible to modify the remaining time using keys 2 and 3.

WEEKLY PROGRAMMER

The weekly programmer allows to program 3 time spans within a day to use every day of the week. The ignition and switch-off times must be within the arc of one day, from 0 to 24 and not over several days:

E.g. switch-on 07:00 / switch-off 18:00 OK
 switch-on 22:00:00 / switch-off 05:00:00 ERROR

First of all the current date and time must be set using the "current date and time adjustment" sequence to give a reference to the function itself.

To access programming press 3, hold it down and press 5 and then release both keys together. Shift using button 5 until **"CHRONO"** appears on display D1.

The table below gives all weekly programmer parameters.

| Parameter | Function | Adjustment Keys | Value | Confirmation Key |
|---------------|---|-----------------|---|------------------|
| | | | Display D1 | |
| ON/OFF | Act./Deact. weekly programmer | 2 or 3 | CHRONO | 5 |
| UT 1 | Time 1st switch-on | 2 or 3 | OFF or from 00:00 to 23:50 | 5 |
| UT 2 | Time 1st switch-off | 2 or 3 | OFF or from 00:00 to 23:50 | 5 |
| UT 3 | Consents for 1st switch on/off for various days | 2 or 3 | ON/OFF 1, ON/OFF 2, ... ON/OFF 7 | 5 |
| UT 4 | Installer parameter | 2 or 3 | 0 | 5 |



| | | | | |
|-------------|---|--------|---|---|
| UT 5 | Time 2nd switch-on | 2 or 3 | OFF or from 00:00 to 23:50 | 5 |
| UT 6 | Time 2nd switch-off | 2 or 3 | OFF or from 00:00 to 23:50 | 5 |
| UT 7 | Consents for 2nd switch on/off for various days | 2 or 3 | ON/OFF 1, ON/OFF 2, ... ON/OFF 7 | 5 |
| UT 8 | Time 3rd switch-on | 2 or 3 | OFF or from 00:00 to 23:50 | 5 |
| UT 9 | Time 3rd switch-off | 2 or 3 | OFF or from 00:00 to 23:50 | 5 |
| UT A | Consents for 3rd switch on/off for various days | 2 or 3 | ON/OFF 1, ON/OFF 2, ... ON/OFF 7 | 1 |

Let's suppose that the weekly programmer function is to be used and 3 time periods are to be used in the following way:

1st time span: from 08:00 to 12:00 every day of the week excluding Saturday and Sunday

2nd time span: from 15:00 to 22:00 only Saturday and Sunday

3rd time span: not used

Let's set the data.

Parameter 0 (D2=UT 0 (flashing); D1=ON]

Use buttons 2 and 3 to activate the weekly programmer by setting the value at ON on display D2.

Parameter 1 (D2=V (flashing); D1=E.g. "08:00"]

Use buttons 2 or 3 to set "08:00", which corresponds to the switch-on time of the 1st time span. To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.

Parameter 2 (D2=UT 2 (flashing); D1=E.g. "12:00"]

Use buttons 2 or 3 to set "12:00:00", which corresponds to the switch-off time of the 1st time span. To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.

Parameter 3 (D2=UT 3(flashing); D1= "OFF 1"]

Activate the first time span for every day of the week except Saturday and Sunday. To do this use keys 2 and 3 in the following way:

- a. key 3 - scroll the various days
- b. key 2 - enable/disable (ON/OFF) the 1st time span for that day

Example:

| Day | Initial value | Function key 2 | Final value | Function key 3 |
|------------|---------------|-----------------------------|--------------------------------------|----------------|
| MONDAY' | OFF 1 | OFF 1 ⇔ ON 1 and vice versa | ON 1 (time span active) | Go to next day |
| TUESDAY | OFF 2 | OFF 2 ⇔ ON 2 and vice versa | ON 2 (time span active) | Go to next day |
| WEDNESDAY' | OFF 3 | OFF 3 ⇔ ON 3 and vice versa | ON 3 (time span active) | Go to next day |
| THURSDAY | OFF 4 | OFF 4 ⇔ ON 4 and vice versa | ON 4 (time span active) | Go to next day |
| FRIDAY | OFF 5 | OFF 5 ⇔ ON 5 and vice versa | ON 5 (time span active) | Go to next day |
| SATURDAY | OFF 6 | OFF 6 ⇔ ON 6 and vice versa | OFF 6 (time span deactivated) | Go to next day |
| SUNDAY | OFF 7 | OFF 7 ⇔ ON 7 and vice versa | OFF 7 (time span deactivated) | Go to next day |

To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.



Parameter 4 (D2=UT 4 (flashing); D1= "00")

N.B. This parameter is reserved for the after-sales service and must not be modified.

Parameter 5 (D2=UT 5 (flashing); D1=E.g. "15:00")

Use buttons 2 or 3 to set "15:00", which corresponds to the switch-on time of the 2nd time span. To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.

Parameter 6 (D2=UT 6 (flashing); D1=E.g. "22:00")

Use buttons 2 or 3 to set "22:00", which corresponds to the switch-off time of the 2nd time span. To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.

Parameter 7 (D2=UT 7 (flashing); D1=E.g. "OFF 1")

Activate the second time span only Saturday and Sunday. To do this use keys 2 and 3 in the following way:

- a. key 3 - scroll the various days
- b. key 2 - enable/disable (ON/OFF) the 1st time span for that day

Example:

| Day | Initial value | Function key 2 | Final value | Function key 3 |
|-----------|---------------|-----------------------------|--------------------------------------|----------------|
| MONDAY | OFF 1 | OFF 1 ⇔ ON 1 and vice versa | OFF 1 (time span deactivated) | Go to next day |
| TUESDAY | OFF 2 | OFF 2 ⇔ ON 2 and vice versa | OFF 2 (time span deactivated) | Go to next day |
| WEDNESDAY | OFF 3 | OFF 3 ⇔ ON 3 and vice versa | OFF 3 (time span deactivated) | Go to next day |
| THURSDAY | OFF 4 | OFF 4 ⇔ ON 4 and vice versa | OFF 4 (time span deactivated) | Go to next day |
| FRIDAY | OFF 5 | OFF 5 ⇔ ON 5 and vice versa | OFF 5 (time span deactivated) | Go to next day |
| SATURDAY | OFF 6 | OFF 6 ⇔ ON 6 and vice versa | ON 6 (time span active) | Go to next day |
| SUNDAY | OFF 7 | OFF 7 ⇔ ON 7 and vice versa | ON 7 (time span active) | Go to next day |

To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.

Parameter 8 (D2=UT 8 (flashing); D1=E.g. "OFF")

Set at "OFF" using buttons 2 or 3, which is found before the time "00:00", in a way to disable the switch-on of the 3rd time period.

To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.

Parameter 9 (D2=UT 9 (flashing); D1=E.g. "OFF")

Set at "OFF" using buttons 2 or 3, which is found before the time "00:00", in a way to disable the switch-off of the 3rd time period.

To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.

Parameter A (D2=UT A (flashing); D1=E.g. "OFF 1")

At this point the values introduced in this parameter have no value as the ignition and switch-off of the 3rd time period have been disabled.

To confirm and continue programming, press button 5.

Press button 4 to go back to the previous parameter.



Press button 1 to escape.

Nota bene: The relative indicator light on the control board will switch on when the weekly programmer is active (see display table description).

TO DEACTIVATE THE WEEKLY PROGRAMMER enter user programming by pressing key 3 and, holding it down, press key 5. Shift using button 5 until **"CHRONO"** appears on display D1 and set **"OFF"** in display D2 using keys 2 and 3. Successively press key 1 to confirm and escape.

The manual controls, from the display or remote control, always remain priority with respect to programming.

DAY-NIGHT TEMPERATURE FUNCTION

The day-night temperature function allows to switch the appliance on/off automatically on the basis of two pre-selected temperatures.

The system allows to set one temperature during the day and another one during the night.

First of all the current day and time must be set using the current day and time adjustment sequence to give a reference to the function itself.

To access the day-night temperature function parameters, press 3, hold it down and press 5 and then release both keys together: once entered, press button 5 and move to parameter b (D2=**UT B**).

Parameter b (D2=UT B; D1=E.g. "06:00")

Using buttons 2 and 3 it allows to adjust the day time start/night time end.

To confirm and continue programming, press button 5.

Parameter c (D2=UT C; D1=E.g. "22:00")

Using buttons 2 and 3 it allows to adjust the day time end/night time start.

To confirm and continue programming, press button 5.

Parameter d (D2=UT D; D1=E.g. "25°C")

Using buttons 2 and 3 it allows to adjust the day time maximum temperature.

To confirm and continue programming, press button 5.

Parameter E (D2=UT E; D1=E.g. "20°C")

Using buttons 2 and 3 it allows to adjust the night time maximum temperature.

To confirm and continue programming, press button 1.

Once exiting the programming, to activate/deactivate the function press 4, hold it down and press 5 and then release both keys together.

The relative luminous indicator will appear/disappear on the control board (see display table description).

N.B. The parameters must only be set with the stove off!

Summary table

| Display D1 | Display D2 | Function |
|------------|------------|-------------------------------------|
| 06:00 | UT B | Start of day time/end of night time |
| 22:00 | UT C | End of day time/start of night time |
| 25°C | UT D | Day time max. temperature |
| 20°C | UT E | Night time max. temperature |

When the stove switches off due to the maximum temperature reached, **“DOFF”** will appear on display D1. The stove switches back on automatically when the room temperature lowers by 3°C with respect to the maximum temperature set.

Es. State of the stove – doff
Maximum temperature set - 25°C

When the room temperature falls below 22°C ($25 - 3 = 22$ °C), the stove will re-start automatically.

N.B. The stove can only re-ignite from the **“DOFF”** state and not from the **“OFF”** state.

The manual controls, from the display or remote control, always remain priority with respect to programming.

PELLET FEED ADJUSTMENT

If the stove has functioning problems owing to the quantity of pellets, adjust pellet feeding directly from the control board.

The problems correlated to the amount of fuel can be divided into 2 categories:

1. LACK OF FUEL:

- ❖ the stove can never develop a suitable flame, tending to remain very low even at high powers
- ❖ at minimum power the stove tends to almost switch off taking the stove into **“NO PELL”** alarm conditions.
- ❖ when the stove displays the **“NO PELL”** alarm, there may be non-burned pellets inside the pot

2. EXCESS FUEL:

- ❖ the stove develops a very high flame even at low power
- ❖ the panoramic glass is very dirty, obscuring it almost totally
- ❖ the pot tends to become encrusted, blocking the holes for air intake due to the excessive pellet feed, as it is only burned partially

N.B. If the problem occurs after only a few months working, check that routine cleaning stated in the stove booklet, has been carried out correctly.

The regulation to be performed is a percentage. Therefore a modification of this parameter will lead to a proportional variation of all stove feeding speeds.



To access the percentage adjustment of pellet feeding, enter the user programming by pressing key 3 and, holding this down, press key 5.

At this point use key 5 to move within the menu until **"UT F"** appears on display D2.

If, inadvertently, progress is made beyond this parameter, exit using key 1 and repeat the operation.

The value **"00"** will appear on display D1: keys 2 and 3 can be used to adjust the percentage increase/decrease desired by 5 points per time (the parameter can be varied with a maximum travel from -50 to +50).

Adjustment table

| | |
|---------------------|---|
| LACK OF FUEL | Increase the percentage value by 5 points and try the stove with the new calibration for at least half an hour. If the problem is attenuated, but not solved, increase by another 5 points. Repeat the operation until the problem is solved. If the problem cannot be resolved, contact the after-sales service. |
| EXCESS FUEL | Decrease the percentage value by 5 points and try the stove with the new calibration for at least half an hour. If the problem is attenuated, but not solved, decrease by another 5 points. Repeat the operation until the problem is solved. If the problem cannot be resolved, contact the after-sales service. |

When the adjustment has been made, press button 1 to conform and escape.

CLEANING

Maintenance operations guarantee correct functioning of the product through time. Failure to comply with these operations can jeopardise the safety of the product.

1. POT CLEANING

The pot must be cleaned every day.

- ❖ remove the pot from the relevant compartment and free the holes using the appropriate fire irons supplied.
- ❖ remove the ash from the pot using a suction device
- ❖ suck the ash deposited in the pot compartment

2. USING THE SCRAPERS

Cleaning of the heat exchangers allows to guarantee constant heat output through time. This type of maintenance must be performed at least once a day. To do this, just use the relevant scrapers positioned in the upper part of the stove, making the high/low movement several times.

3. CLEANING THE ASH COLLECTOR TRAYS

The ash collection trays must be emptied when necessary by removing the ash drawer in the lower part. Remove the drawer as follows:

- ❖ press the small lower door down and turn it outwards
- ❖ turn the handle by 90° in a way that the drawer releases from the fixed body of the stove
- ❖ extract the drawer and empty the ash

Carry out the procedure in the reverse order to re-mount the drawer.



figure 9.1



figure 9.2




figure 9.3



figure 9.4



figure 9.5

4. CLEANING THE HEAT EXCHANGER (Monthly)

The heat exchangers chamber must be cleaned every month as the soot deposited on the rear of the cast iron hearth wall blocks the regular flow of fumes.

To access the heat exchangers, remove the central piece from the hearth wall, following the operations described below:

- ❖ Remove the pot from its location
- ❖ Turn the lockbolt by 180°.
- ❖ Take the extractable cast iron and turn it downwards.

Finally, slide it from the combustion chamber by pulling it towards yourself, paying attention to the 2 lateral cast iron hooks below.

Once the heat exchanger compartment can be accessed use the supplied fire irons to remove and scrape the soot deposited and only then use the suction device to completely remove the ash. When cleaning has been completed, re-position the extractable cast iron with the opposite movement used to remove it. When the hearth wall has been positioned, turn the lockbolt by 189° to take it to its original position.

5. DOOR, ASH DRAWER AND POT GASKETS



figure 9.6



figure 9.7



figure 9.8



figure 9.9

The gaskets guarantee the tightness of the stove and its consequent good functioning.

These must be checked regularly: if they should be worn or damages they must be replaced immediately. These operations must be carried out by a qualified technician.

N.B. For correct functioning, the stove must undergo routine maintenance by a qualified technician, at least once a year.

If the power supply cable is damaged, it must be replaced by the after-sales service or by a similarly qualified person, so as to avoid all risks.

CONNECTION TO THE FLUE

Suck and clean the pipe that leads to the flue yearly or anytime that it is necessary. If there are horizontal tracts the residues must be removed before they can obstruct flue passage. **NON-CLEANING jeopardises safety.**

POT DIVIDER

The Delizia model is supplied with a divider fixed to the pot using a screw. This allows to optimise the stove combustion processes.




figure 10.1

ATTENTION!!

Removal of the divider jeopardises the safety of the product and leads to the immediate voiding of the warranty period. In the case of wear or deterioration request after-sales assistance for replacement of the part (replacement that is not under guarantee as the component is subject to wear).

PRODUCT DISPLAY TABLES

| SIGNALS | | |
|----------------------------|---|---|
| Signals Display | Reason | Solution |
| WAIT FOR COOL | A new ignition is attempted when the stove has just been switched off (normal switch-off or caused by an alarm). | When the stove switches off (normal or caused by an alarm) it is necessary to wait until it cools down completely and then clean the pot. The stove can only be re-ignited when these operations have been performed. |
| MANUAL | Room thermostat set at maximum value. | In this mode the stove no longer has a temperature level but works in manual with 5 powers. To escape this function just lower the room temperature using button 2. |
| MINIM- | Room thermostat set at minimum value. | In this mode the stove only works at 1st power independently from the power set. To escape this function just raise the room temperature using button 3. |
| T ON | An external thermostat has been connected. The room thermostat probe is disconnected. The room thermostat probe is cut-off. | To exclude any external thermostat just disconnect it. Other restoration operations must be carried out by an authorised technician. |
| ST-BY | Stove off waiting for re-ignition. | In this mode the machine can be switched on/off using an additional thermostat (see " <i>Mechanical thermostat function in energy saving mode</i> "). To exclude the following function just raise the room temperature using button 3. |
| DOFF | Stove off due to " <i>Day-night temperature function</i> " and in Stand-by to re-ignite. | To exclude the re-ignition of the stove due to the " <i>Day-night temperature function</i> " just hold button 1 down for 3 seconds, taking the stove to OFF . To exclude the function completely, press button 4 and, holding it down, press 5. |
| COOL BLACK OUT | No current on the main power supply. | After the complete switch-off cycle the stove will re-ignite automatically. |
| CLEANING | Automatic pot cleaning is in progress. | The automatic pot cleaning is performed at pre-established intervals of continued working. The automatic cleaning does not start if the stove is in 1st power. |

ALARMS

| Signals Display D1 | Reason | Solution |
|-----------------------------------|---|--|
| | Indicates the presence of an alarm | It is on in the presence of one of the alarms described below and is accompanied by the relative signal in display D1, which identifies the cause. To reset the alarm, just hold key 1 down for 3 seconds when the stove is completely cold. If flashing it indicates the deactivation of the depression sensor. The sensor restoration operations must be carried out by an authorised technician. |
| EXTRACTOR FAIL. | The fumes motor is blocked. The speed control probe is broken. No power supply to the fumes motor. | The restoration operations must be carried out by an authorised technician. |
| FUMES PROBE KO | The fumes probe is broken. The fumes probe is disconnected from the board. | The restoration operations must be carried out by an authorised technician. |
| HIGH GAS TEMP | The tangential fan is faulty. Excessive pellet feed. No power supply to the tangential fan. | Adjust pellet flow (see " <i>Pellet feed adjustment</i> "). Other restoration operations must be carried out by an authorised technician. |
| DEPRESSION KO | The flue exhaust pipe is blocked. The air vent is blocked. The combustion chamber is dirty. The depression sensor is faulty. The ash drawer is not closed correctly. The door is not closed correctly. | Check cleanliness of the fumes pipe and the combustion chamber. Check that the air vent is not blocked. Check hermetic closure of the ash drawer. Check hermetic door closure. Other restoration operations must be carried out by an authorised technician. |
| IGNITION FAILURE | The pellet feed-box is empty. The ign-plug is faulty or out of position. Pellet feed calibration inadequate. | Check for the presence of pellets in the feed-box. Check the procedures described in the " <i>Ignition</i> " chapter. Other restoration operations must be carried out by an authorised technician. |
| IGNITION FAILURE BLACK OUT | No current during the ignition phase | Take the stove to off conditions using key 1 and repeat the procedures described in the " <i>Ignition</i> " chapter. Other restoration operations must be carried out by an authorised technician. |
| NO PELLETS | The pellet feed-box is empty. No pellet feed. The loading motor must still settle. The motor reducer does not feed pellets. | Check for the presence of pellets in the feed-box. Adjust pellet flow (see " <i>Pellet feed adjustment</i> "). Other restoration operations must be carried out by an authorised technician. |



| | | |
|-----------------------------------|---|--|
| WAIT FOR COOL. + ALARM | Attempt to release the alarm with stove still in cooling mode | Every time the stove displays one of the alarms listed above it will switch-off automatically. The stove will block any alarm release attempt during this phase, showing the alarm itself and WAIT FOR COOL. alternately on the display. The alarm can only be released using button 1 when it switch-off has been completed. |
| TELEPHONE ----- | Telephone number display. | During the display of an alarm, the type of alarm detected and the telephone number of the After-sales Centre will flash alternatively. If the number has not been introduced the display will show hyphens. |

LUMINOUS INDICATORS

| Signals Display | Reason | Solution |
|---|---|--|
|  | It indicates the <i>Weekly programmer</i> function. | It is on when the weekly programmer is active. For all settings relative to the following function see the " <i>Weekly programmer</i> " function. |
|  | It indicates the <i>Room thermostat</i> function. | It is on/off when the room temperature is below/above the set threshold. To modify the temperature threshold, use keys 2 and 3 during normal functioning. |
|  | It indicates the " <i>Day-night temperature function</i> " | It is on when the " <i>Day-night temperature function</i> " is active. To enable/disable the " <i>Day-night temperature function</i> " just press button 4, and holding it down, press button 5. For all settings relative to the following function, see the Day-night temperature function paragraph. |
|  | It indicates deactivation of the ign-plug. | It is on when the ign-plug is deactivated. To restore the functioning of the component, contact an authorised technician. |
|  | It indicates functioning of the fumes motor. | It is on when the fumes exhaust motor is active. If it flashes, contact an authorised technician. |
|  | It indicates functioning of the pellet feed motor. | It is on when the pellet feed motor is active. During normal functioning the following indicator switches on flashing. |
|  | It indicates functioning of the tangential fan. | It is on when the tangential fan is active. |
|  | DIVINA PLUS version only Indicates the motor functioning for ducting. | It is on when the ducting motor is active. If flashing, check the " <i>Mechanical thermostat functioning for ducting motor control</i> " paragraph. |
|  | DIVINA PLUS version only Indicates the status of an additional thermostat. | Normally this indicator is ALWAYS on. When an external thermostat is connected for control of the ducting motor, the indicator light is on when the external contact is closed. |
|  | It does not indicate any functioning. | This indicator must always be off. |
|  | It indicates the communication between remote control and stove. | Every time a key is pressed on the remote control the indicator must switch on. If the indicator is always on it indicates that the communication between remote control and stove is blocked. To restore the functioning of the component, contact an authorised technician. |

WARRANTY

EXTRAFLAME S.p.A. reminds you that the manufacturer is the owner of the rights envisioned by the Legislative Decree dated 2 February 2002, n. 24 and the following warranty does jeopardise these rights.

This warranty certificate, granted by Extraflame S.p.A., with offices in Montecchio Precalcino (VI), via dell'Artigianato 10, refers to all stove components supplied by Extraflame S.p.A. and is extended to the free repair or replacement of any part of the defective appliance, on the condition that:

- ❖ the same defect is detected within 2 YEARS from the product delivery date and is communicated to an Extraflame S.p.A. After-Sales Centre within 2 months from its discovery;
- ❖ is recognised as such by an Extraflame S.p.A. After-Sales Centre

No cost or expense will be charged to the client for interventions that the Extraflame S.p.A. After-Sales Centre will carry out if provided by the warranty certificate.

WARRANTY CONDITIONS

The warranty is considered valid on the condition that:

1. The stove is installed in compliance with the Standards in force on this subject, the prescriptions contained in this manual and professionally qualified staff.
2. The customer has filled-in and signed the warranty certificate, validated by the Extraflame S.p.A. Technical After-sales Service or the dealer.
3. The warranty document, filled-in and accompanied by the receipt, must be kept and shown to staff of the Extraflame S.p.A. Technical After-sales Service in the case of intervention.

The warranty is not considered valid in the following cases:

1. The warranty conditions described above have not been respected.
2. Installation has not been performed with respect to the Standards in force regarding the provisions described in this manual.
3. Negligence of the customer due to lack of or incorrect maintenance of the product.
4. Presence of electric and/or hydraulic plants that do not comply with the standards in force.
5. Damages deriving from atmospheric agents, chemicals, electro-chemicals, improper use of the product, modifications or tampering of the product, inefficacy and/or unsuitability of the flue and/or other causes not deriving from the manufacture of the product.
6. Damage caused by normal corrosion or deposits typical of the central heating systems (condition valid for water products).
7. Damage caused to the stove owing to the use on non-original spare parts or consequences of interventions carried out by technical staff not authorised by Extraflame S.p.A.
8. Improper or negligent use of the stove.
9. All damage caused by transport. It is therefore recommended to carefully check the goods on receipt, informing the dealer of any damage immediately, making a note on the transport document and on the carrier's copy.



Extraflame S.p.A. is not liable for any damage/injury that can, directly or indirectly, affect persons, objects and pets as a consequence of failure to comply with the prescriptions indicated in this manual and the standards in force regarding installation and maintenance of the appliance.

The following are excluded from the warranty:

- ❖ The gaskets, all ceramic or toughened glass, coverings and cast iron or Ironker grids, the painted, chrome or gold -plated details, the majolica, the handles and the electric cables.
- ❖ Colour variations, crackles and slight size differences of the majolica parts are not a reason for claims, as they are natural features of the materials themselves.
- ❖ Masonry work.
- ❖ The plant particulars for the production of domestic water not supplied by EXTRAFLAME S.p.A. (water products only).
- ❖ The heat exchanger is excluded from the warranty unless an adequate anti-condensate circuit is realised (water products only).
- ❖ The warranty also excludes any calibration or regulation interventions of the product in relation to the type of fuel or the type of installation.
- ❖ The operations required to vent the air from the hydraulic system or from the product.

Further clauses

If during normal use of the product defective or badly working particulars should be detected, the replacement of such particulars will be free of charge, ex dealer who made the sale or ex our area After-Sales Centre.

For products sold abroad, the same situations will always be free of charge, ex our establishment, with the exception of particular conditions agreed during negotiations with the foreign distributor.

In case of replacing particulars, the warranty is not extended.

No compensation will be paid for the time the product is inefficient.

This is the only valid warranty and no one is authorised to issue others in name or on behalf of EXTRAFLAME S.p.A.

Recommended inspection (with payment)

Extraflame recommends that the functional inspection of the product is performed by an Extraflame authorised Technical After-Sales Centre, which will supply all information for correct use.

WARRANTY INTERVENTION

The request for information must be sent to the dealer.

LIABILITY

EXTRAFLAME S.p.A. does not grant any compensation for direct or indirect damages caused or dependant by the product.


LAW COURT

The Vicenza Law Court is elected as the competent court for any disputes.

STUFA PELLETTA LUCREZIA IDRO BORDEAUX



etichetta codice a barre



12851750

Lotto N. Ind.M. 0012

MODELLO 08
MATRICOLA 74362
DATA 26-09-2009
LOTTO

CONTINUITA' CIRCUITO
PROTEZIONE EQUIPOTENZ.

Corrente [A] = 17.9

Tempo [sec] = 2.0

Resist. [ohm] = 0.06

TENSIONE APPLICATA

Tensione [V] = 1865

Tempo [sec] = 2.0

Corrente [mA] = 0.00

RESISTENZA ISOLAMENTO

Tensione [V] = 500

Tempo [sec] = 2.0

Resist. [Mohm] > 20

COLLAUDO POSITIVO

Extraflame

Stufe a Pellet



EXTRAFLAME S.p.A.

Via Dell'Artigianato, 10
36030 MONTECCHIO PRECALCINO
Vicenza - ITALY
Tel. 0445/865911
Fax 0445/865912

<http://www.lanordica-extraflame.com>

E-mail: info@extraflame.com

Extraflame reserves the right to vary the features and data given in this document at any time without forewarning, in order to improve its products.

This manual, therefore, cannot be considered as a contract for third parties.

This document is available at www.extraflame.it/support

004275277 - ENGLISH
Manuale utente Delizia
REV 013 081009